

General & Spares Instruction

3P221A

tiller

and accessories spare parts

one Riagina

LISTRALIA piriock Australia Pty Ltd piriock Suspension TIEN VINGIN Gatta Sport Ltd ## antime Supply LLC +1 860 767 0468 5.A. 11. 4580 0444

The experts in ropeholding

TUBKEN THEO 212 686 99 15 UNITED MUNICIPAN MARKHONLESSAN THEORY SEPTION SEPTION THEORY SEPTION SEPTION THEORY SEPTION SEPTION SEP

EW CALEDONIA 3and & 00 Ltd 75 j48 19 54 54 R +ac HUNGARY Then Vacht-Skippe 8 87 01 20 Marine SPA 3 DZ 569 5906 12 5069 14668320

Spinlock world service

ruine Spinlock accessories

foz – Comendo gos Nauticos, Lo 226 179 986 LAND -Je-Ritd -48 22 869 986 RTUGAL ey d.o.o. 36 45 302 444

Should you need any help in obtaining spare parts, or advice with repairs, your local Spinlock expert can provide a fast and professional service.

customer Ser Spinlock's after sales

worldwide through our distribution network. service is available

<u>Maintenance</u>

How to install the grey pivot bearing on a

metal or composite tiller.

From underside of tiller drill hole Ø16.5mm (21/32),

do not drill through top skin / top wall:

Drill a through hole ø12.5mm (1/2").

on a wooden tiller.

Drill a through hole ø12.5mm (1/2").


Secure with the 2 x Nº8 screws, (supplied)

Insert the grey socket. Varnish the hole How to install the grey pivot bearing

marine environment. Spinlock products are made from the best quality materials for durability and low maintenance in a harsh

For reliable operation, flush your tiller extension regularly with FRESH water to remove salt.

plastic components and attracts debris into ball lock based lubricants like "WD40" will accelerate the ageing of Do not lubricate locking mechanism. Mineral oil & solvent <u>Never sail with a damaged or bent tiller extension.</u>



using wooden tiller. Shock Absorber Assembly

Woodscrews

Fix it with 2 x countersunk botts M5 and M5 Nyloc

flush with the tiller.


Insert the grey pivot bearing

Around the tube, the top external surface must be gel-coat to avoid water penetration in fibres. If the tiller is in composite, protect the hole using is required to support pivot bearing.

Insert the grey backing spacer tube (E-Sleeve) this

nuts (supplied).

Shock Absorber Assembly using hollow tube or composite



E-FASTPIN ... Full Swivel Joint Release Pir E-SHOCK ... Shock Absorber E-CLIP ... Tiller Clip **E-BUTTON** ... Control Button E-TUBE ... Insert for hollow / composite tille

GRIP ... Tube Sleeve Grip OINT ... Full Swivel Joint with Fastpin

... Full Length Sleeve F-DIAROI O Full Universal Joint