

montage handleiding - mounting instruction - montageanleitung - monteringsanvisningar - istruzioni di montaggio

NR.	QTY.	
①	1	
②	2	
③	1	
④	2	
⑤	1	
⑥	2	



**I**

- Move the spindles horizontal facing each other.
- Place the anti-vibration foam (nr. 6) on top of the spindles.
- Match the spindle-shaft diameter with the correct recess from the spindle-inserts (nr.2).
- Position the spindle-inserts (nr. 2) with the anti-vibration foam (nr. 6) on the spindle-shafts.

**II**

- Pressure down the inserts (nr. 2).
- Slide the lock-housing (nr.1) over the spindle-inserts (nr. 2).

**III**

- Slide the locking-mechanism (nr. 3) over the housing (nr. 2).
- Turn the key (nr. 4) clockwise to lock the device.